



Efx/Cab Card



No	Delaytype	Original	Para 1	Para 2	Position
1	Tube Echo	Maestro EP-1 Echoplex	Mix	Feedback	Pre
2	Tape Eco	Roland RE-101 Space Echo	Mix	Feedback	Pre
3	Analog	Elec. Harmonix Memory Man	Mix	Feedback	Pre
4	Digital	Mono Delay	Mix	Feedback	Post
5	Ping-Pong	Stereo Spread Delay	Mix	Feedback	Post
6	Sweep Echo	Line6 DL4 Filter Delay	Mix	Feedback	Post
No	Modtype	Original	Para 1	Para 2	Position
1	Tremolo	64' Fender Twin Reverb	Mix, Speed, Wave	Mix	Post
2	Chorus	Roland CE-1 & TC Electronic	Mix, Speed, Depth	Depth	Post
3	Flanger	A/DA Flanger	Mix, Speed, Depth	Feedback	Post
4	Phaser	MXR Phase 90	Speed	Feedback	Pre
5	U-Vibe	Uni-Vibe	Speed, Depth	Depth	Pre
6	Rotary	Leslie 145	Slow/Fast	Tone	Post
No	Cab Size	Original	Modell Knob		
1		No Cabinett	Line 6 Clean		
2	1x6	Supro S6616	Line 6 Crunch		
3	1X10	Gibson Explorer	Line 6 Mood		
4	1x12	'53 Celestion Blue Bell	Line 6 Insane		
5	1x12	Fender '64 Deluxe	Jazz Clean		
6	2x10	Fender '63 Vibroverb	Blackface Lux		
7	2x12	Fender '65 Twin	Tweed B-Man		
8	2x12	Matchless Chiefian	Double Verb		
9	2x12	Roland JC-120	Match Chief		
10	2x12	Vox '67 AC-30	Class A-30 TB		
11	4x10	Fender '58 Bassman	Plexi 45		
12	4x12	Marshall '67 with Greenbacks 20's	Plexi Lead 100		
13	4x12	Marshall '68 with Greenback 25's	Brit J-800		
14	4x12	Marshall with Celestion T75's	Treadplate		
15	4x12	Marshall with Celestion V30's	Solo 100		
16	4x12	Mesa Boogie with Celestion V30's	Gib Explorer		